



Contact us info@eleventargets.hu

4 LEGS STAND



ELEVEN ST4A

190x120x115 cm (195x120x17cm) 16kg



Parts:

- A - Left leg
- B - Right leg
- C - Horizontal holders
- D - Arm holder

Accessories package contains:

- F - 8 pcs Screws with nuts
- G - 1 pc Allen wrench

Further tools needed:

- flat screwdriver
- rubber headed hammer (not included)




Manufactured by

HF ELEVEN KFT.
H-1163
Budapest, HUNGARY
Margit utca 28.

www.eleventargets.hu

info@eleventargets.hu

USERS MANUAL for 4 legs stand



Instruction for assembly

- 1, After unpacking please prepare the „C” and „D” holders with nuts. Push the nuts into bottom of the holes and turn with a screwdriver to the direction of screw.
- 2, Lay down the „B” leg to the ground and push the „C” elements into the leg in the order as shown in the picture.
- 3, Fasten all three „C” elements with „F” screws
- 4, Lay down the „A” leg to the ground and push the „C” elements into the leg.
- 5, Fasten all three „C” elements with „F” screws
- 6, Turn up the stand to half opened standing position and fit the „D” holder between the holder arms.
- 7, Fasten „D” elements with two „F” screws



- 8, Open stand fully and check that the stopper fits on the horizontal holder

- 9, The stand is ready to use

In factory settings the stand is 13 degree from vertical. If you want to use for indoor you may change to 8 degree.

The rotating axle in backside of horizontal holder arms has two positions. Remove the screw from the hole and use the other hole for decreasing the angle of leg.

Maximum size of buttress: 150x150x30 cm
Maximum load of stand: 100 kg

For your safety:

The 4 leg Stand is very stable, but additional anchorage maybe needed. Please use with safety anchoring when using it outside.

Please, do not use the stand without fixing the buttress.